

Protection of windows during the construction phase

Cover the surface before plastering

Only use adhesive tapes that are approved for acrylic lacquers.

Approved adhesive tapes:

3M: Scotch 244 paper tape

kip: 308 FineLine-tape

kip: 810 Duoband

Storch Brand Tape 4931 "The Golden One"

Tesa: Surface protection tape 4438 UV

The adhesive tapes should be removed within 2 weeks.

(Follow the manufacturer's instructions. Do not use sharp objects)

Building moisture must be allowed to evaporate (risk of paint damage)

Important:

- During construction activities in winter: heat and ventilate at the same time.
- Ventilate well during plastering and screed work.
- Ventilate urgently, if there is condensation on the inside of the window.
- Ventilate intermittently, do not leave in a permanently tilted position.
-

Clean only with neutral all-purpose cleaners.

Abrasive cleaners, acids or aggressive cleaners with solvents will damage the surface.